www.adseries.com

ASERIES

Electronic Solutions
Design & Manufacture



AVX460 Atmos Deployment




























Solutions





Function AVX460-10

Four Button Demo with HDMI – Summary of basic function

- Default play of video loop (no Audio)
- Demo Button will cause Full Codec Audio to play via TV (Set at Default level)
- Sound Bar Button will cause Full Codec Audio to switch from TV to SB at predefined level. The volume buttons will now be enabled allowing the volume to be adjusted in the player.
- Repeated button press will toggle functions
- On timeout the TV and SB will return to default setting.
- Keep awake signal sent to soundbar

Custom function available





Function AVX460-1H

Four Button Demo over HDMI – Summary of basic function

- Default play of video loop (no Audio)
- Demo Button will cause Full Codec Audio to play via TV (Set at Default level)
- Sound Bar Button will cause Full Codec Audio to switch from TV to SB at predefined level. The volume buttons will now be enabled allowing the SB volume to be adjusted.
- Repeated button press will toggle functions
- On timeout the TV and SB will return to default setting.
- TV and SB will be kept awake / auto turned on if turned off

Custom function available





Function AVX460-1H + H-SWITCH124

Ten Button Demo over multi HDMI – Summary of basic function

- Default play of video loop (no Audio)
- Demo Buttons will cause Full Codec Audio to play via selected device
 - For TV's this will be at default volume (Set at Default level)
 - For Sound Bar Buttons, the volume buttons will now be enabled allowing the SB volume to be adjusted.
 - Content can also be switched
 - Selected product illumination output
 - On timeout the TV and SB will return to default setting.
- TV and SB will be kept awake / auto turned on if turned off Custom function available



www.adseries.com




Function AVX460-1H + BBB + H-SWITCH124

Five Button Demo over HDMI

- Default play of video loop (no Audio) (or attractor loop flag option ideal)
- Demo Button / next button will cause Audio to play to soundbar 1
- Repeat button press of demo button will advance to the next content video in the play list
- 60secomd timeout to default loop, this will also reset the SB volume levels.
- Sub on /off button will toggle audio between the two sound bars, will cause demo start if in default mode.
- The volume buttons will be enabled when audio is active on both SB volume.
- On timeout the TV and SB will return to default setting.
- SB will de kept powered ON at so no switch over delay
- One final button to return the play to default (replicate the timeout) play should be provided
- Ability to locally set default volume level



www.adseries.com



AVX460-1HS Player HDMI OUT (1)

HDMI OUT (2)

HDMI OUT (3)

H-HDMI OUT (4)

HDMI OUT (4)

Player Function

- Content management
- Content select common loop / dedicated product file
- Attractor option
- Vol +/- PCM Format
- Optical out
- Dolby Atmos









Global


- Button Functions
- Output LED's
- Timeouts
- Configuration
- Data collection

H-SWITCH124 Function

- CEC emitter per channel
- HDMI out switch / split
- Vol +/- request RAW Format

4K TV OPTION






Function AVX460-2HS + H-SWITCH124

X1

Multi Button Demo over HDMI

- Default play of video loop (no Audio)
- Individual product Demo Buttons will cause Full Codec Audio to play SB at predefined level.
- The volume buttons will now be enabled allowing the SB volume to be adjusted.
- On timeout the SB's will returned to default setting.
- SB's will be kept awake





Function AVX460-1H + H-SWITCH124

Ten Button Demo over multi HDMI – Summary of basic function

- Default play of video loop (no Audio)
- Demo Buttons will cause Full Codec Audio to play via selected device
 - For TV's this will be at default volume (Set at Default level)
 - For Sound Bar Buttons, the volume buttons will now be enabled allowing the SB volume to be adjusted.
 - Content can also be switched
 - Selected product illumination output
 - On timeout the TV and SB will return to default setting.
- TV and SB will be kept awake / auto turned on if turned off






Deployment Options

- 1) The timeout to default play can be on the Demo or SB button last press or any last pressed button to ensure no timeout during demo.
- 2) 3) The hand over and hand back between the TV and SB will be seamless.
- TV volume adjust is expected to be included by October 2018.
- Additional SB (3 max) could be added with the SB button used as a 'next' function.





Deployment Options

- Default play is from the AVX460 (on power up)
- One button will switch the input to the game system.
- 1) 2) 3) 4) There will be a timeout to auto switch back to the AVX460.
- If the button is pressed more than once the input will toggle between states.





Deployment Options

- 1) The timeout to default play can be on the Demo or SB button last press or any last pressed button to ensure no timeout during demo.
- 2) 3) The hand over and hand back between the TV and SB will be seamless.
- TV volume adjust is expected to be included by October 2018.
- Additional SB (3 max) could be added with the SB button used as a 'next' function



www.adseries.com

Option 50 AVX 460-1HE + H-SWITCH124 with DIX www.adseries.com

SERIES

Store TV channel

> AVX460-1HE **Player**

H-SWITCH124 10 Button interface **HDMI**

HDMI OUT (4 нрмі опт (з

CEC contro

CONTROL

Switch Function

- Feed switcher
- Controlled support of 4 / 8 **HDMI** outputs
- **Deliver Demo** product control

4K TV OPTION

Player Function

- Content management
- Content select common loop / selectable
- Store TV Attractor
- Vol +/- PCM Format
- Optical out
- **HDR & Dolby Atmos** support



Deployment Options

- 1) The timeout to default play can be on the Demo or SB button last press or any last pressed button to ensure no timeout during demo.
- 2) The hand over and hand back between the TV and SB will be seamless.
- 3) TV volume adjust is expected to be included by October 2018.
- Additional SB (3 max) could be added with the SB button used as a 'next' function